



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8542748	Literature Parts Installation	5	3952499	(60 Hz.)	22	3390646	(8-18 x 5/16)
		Instructions Use & Care Guide	6	8528154	,	23	3977194	
	3954161 8542754		7	000000	End Cap, Console (L.H. & R.H.)	24	3977195	Knob, Timer
	3952874	Cycle Feature Wiring Diagram	8	692993 3978584 348689	Biscuit		3957752 3957753	
2	3406288	Harness, Console Wiring (Automatic)	9	694091	Mounting (4)	25	3937733	Knob, Push-To-Start
		(Includes Illus. 2A, 2B & 2C)	10 11	3362987			3957800 3957801	
2A	3350130		12	8054142	Knob	27	3957796	Knob, Control (2)
		(Connects With Main Dryer	14	693151	Temperature	28	3957797	
2B	696073	Harness)	15	3400860	Lock (2)	20	3957841	(Washer)
ZD	090073	Connector	16	3406720	Lock (2)	29	3957842	Biscuit
		(Connects With Lower Automatic	16	3400720	(60 Hz.) (Dryer)	29	2057024	Knob, Timer (Washer)
2C	3948614		40	2077456	(Timer Motor Not Serviceable)	24	3957821 3957822	
		(Connects With Automatic Timer)	18	3977456	Push-To-Start	31 32	692983	Lock, Console (2) Buzzer
			19 21		Bumper, Console (5) Clip, Console			

DRYER FRONT PANEL AND DOOR PARTS



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3406108	Door Switch	10	685203	Clip, Felt	14	3389441	Catch, Door
2	697773	Screw, 6-20 x 7/8			Pad (2)	15		Handle, Door
4		Panel, Front	l 11	696144	Strike, Panel		686711	White
	692619	White	12		Screw, Door		3978592	Biscuit
	3978587	Biscuit	'-		Switch	19	694091	Screw, Door
5	3390734	Seal, Door			Mounting (2)			Mount To
6		Door, Rear	13	343641				Hinge & Panel (10)
7		Door, Front	'	0.00	10–16 x 1/2 (2)	20	348023	Hinge & Pin,
	348205				(Front Panel			Door (2)
	3978598	Biscuit			To Side Panel)			(_)
9		Bearing & Seal			i o olao i alion			


DRYER CABINET AND MOTOR PARTS



DRYER CABINET AND MOTOR PARTS

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	660658	Clamp, Motor Mounting (2)	18	686770	Support, Protector	29	3402287	Panel, Side (R.H.) White
2	8538265	• ,	20 21	8066064 8066051	,	30	3978590 693145	Biscuit Latch, Lid
5	696541	Bracket, Motor			(60 Hz.)	31		Closure, Control
6		Panel, Rear	22	691366	,		000704	Area
7		Screw, 10-16 x 1/2			Assembly		692781	White
8	3394228	Cover, Terminal Block	23	692771	Nut, Idler Bracket To Base	32	3978599 354975	
9	90296	Clip	24	3399632	Base, Dryer			(Lid Latch
10		Panel, Side (L.H.)	25	692400	Nut, Push-In			Mounting)
	3402293 3978589		26	692926	Cove, Transition Panel (Black)	33	693304	Screw & Washer (2) (Transition Panel
14	3399602	Elbow, Upper	27		Panel, Transition			To Closure)
15	3394083	Clip, Front Panel (2)		692933 3978591		34	697776	Screw, Ground (10-32 x 5/8)
16	98234	Clip, Ground	28	692641	Top, Dryer	35	3390631	
17	3399603	Elbow, Lower				36	661606	Capacitor, Motor Start (Automatic Washer)
						37	357030	Clamp, Capacitor

DRYER BULKHEAD PARTS




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


DRYER BULKHEAD PARTS

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1 2		Screw, 10–16 x 1/2 Clip, Air Duct To Bulkhead	20 21		Resistor Assembly Shaft, Drum Roller (R.H.)	36A	717252	Receptacle, Terminal (2–Way) (Connects With
3	8566186	Air Duct & Bracket	22 23	695943 3394508				Door Switch Harness)
4	90767	Screw, 8-18 x 3/8	24	685207	Baffle, Drum (3)	36B	3395683	Receptacle,
5		Thermostat, Internal Bias	25	97787	Screw, Baffle Mounting (6)			Multi–Terminal (Connects With
6	3393008	Screw, Terminal Block To	26	345648	,	37	693141	Motor)(Dryer) Clip, Wiring
_		Bracket (2)	27	695931			0.404.4	Harness (3)
7		Block, Terminal	28		Lint Screen	38		Terminal
8	3388703		29	8531967	Cover, Lint	39	279457	Wire Kit (For
9		Screw, 8–18 x 5/8		000007	Screen Outlet			Heater Element
10	3398161	Clip, Heater Box To Bulkhead	30 31	690997 3399506	Tri–Ring (4) Shaft, Drum			Wiring Harness Repair)
11	3401380	Heater Box			Roller (L.H.)	40		Drum, Hole Plug
12	3403586	Element, Heater	32		Roller, Support (2)	41	279393	Screw Kit
13	339956	Seal, Air Duct To Bulkhead	33 34	348197 3359452	Washer, Support (4) Nut, 3/8–16 (2)			(For Terminal Block)
14	696426	Wheel, Blower	35		Screw, 10-16 x 3/8	42	279318	Terminal, Tinned
15	8572767	Thermal Limiter 195°F (91C)	36	3406941				& Brass (3) (Includes Illus. 41)
16	8066094	Seal, Fan Scroll			(Includes Nos.36A, 36B)	43	697776	Screw, Ground (2) (10–32 x 5/8)
17	696418	Fan Scroll			,	48	359702	Cap, Screw
18		Screw, 8-18 x 1/2				49		Clip, Strain
19		Thermostat, Heater Box (200°F)					20000	Relief

DRYER SUPPORT AND WASHER PARTS




WASHER TOP AND LID PARTS



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	2200040	Lid White	6	692985	Clip, Spring (2)	10	358684	Strike, Lid
	3398848 3398849		7		(Top To Cabinet) Top	11	3400030	Switch Screw, Ground
2		Bumper, Lid (2)	'	384693	- 1	''	3400030	(10–24 x 1/2)
3		Hinge, Lid (2)		3978593	Biscuit	12	8533959	Nut, Ground
4	3351355	Screw, Lid	8	21258	Bearing, Lid			Screw (10-24)
		Hinge Mounting (4)			Hinge (2)	13	3355806	Switch, Lid
5	343641	Screw, 10-16 x 1/2	9	3356311	Screw & Washer, Lid Switch Shield (2)	14	90016	Clip, Harness Routing


WASHER CABINET PARTS




WASHER CABINET PARTS

Illus. No.	Part No.	DESCRIPTION
1 2 3	356746 343641 9740848	Clip, Condenser Screw, 10–16 x 1/2 Screw, Mixing Valve Mounting (8–18 x 1/2)
4 5	370451 3952163	Clamp, Hose Valve, Water Mixing
7	692699	Hose, Water Inlet (Siphon Break To Mixing Valve)
8	696013 3978594	Cabinet White Biscuit
10 11 12	696710 692400 660975	Hose, Drain Nut, Push-In (2) Plug, Top To Cabinet
13 15 16 17 18	8557915 356471 356363 272861 696394	Connector, Hose Cap, Siphon Break Siphon Break Clamp, Hose Hose, Water Inlet (Siphon Break To Tub Ring)
21 22 23 24	660628 3394083 358652 359364	Clamp, Hose Clip, Front Panel (2) Link, Leveling Clip, Leveling Mechanism (2)
25 26 27	98234 345670	Clip, Ground Lock, Top (2) Panel, Front
28 29 30	692628 3978596 367594 358594 3400000	White Biscuit Foot, Front (2) Foot, Rear (2) Screw, 10–24 x 3/8 (Washer Cabinet To Dryer Supports)
32	3390046	Protector, Edge


BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS



MACHINE BASE PARTS




TUB AND BASKET PARTS




Illus. No.	Part No.	DESCRIPTION
1	3355758	Cap, Agitator
2	358237	Screw & Washer (5/16–24 x 1)
3 4	63840 3349098	Filter, Agitator
5	64175	9
6 7	21366 3359587	Nut, Spanner
8	3351985	
9 10	8066082 389140	
11	3949550	
12	3363366	• *
13	8066201	Hose, Tub To Pump
14	352155	Clip, Retaining
15	356398	Tube, Drain Off
16	357640	
17	383727	

WATER SYSTEM PARTS




GEARCASE PARTS



BRAKE AND DRIVE TUBE PARTS

For Models: LTE5243DQ5, LTE5243DT5 (Designer White) (Biscuit)




Illus. No.	Part No.	DESCRIPTION
1	387948	Brake And Drive Tube (Complete)
2	62658	
2 3 4	356427	Seal, Drive Tube
4	64027	Tube, Basket
		Drive (Includes
		Illus. 3, 4, 5 & 9)
5	64035	3,
6 7	64232	, , ,
7	62703	3,
_		Spin Tube
8	3353956	1 ,
0	00740	Spring (2)
9		Spring, Brake
10	3355360	,
11	CC1E1C	Spring
11	661516	Cam, Brake Release
12	63033	Sleeve, Cam
13	64194	
13	04134	Cam
14	90368	

FOLLOWING PARTS NOT ILLUSTRATED


285208 Lubricant (Use Only In Brake Shoe Assembly On Roller & Pin)

PRODUCT ACCESSORY PARTS



Illus. No.	Part No.	DESCRIPTION
1	279823	Side Exhaust Extension Kit (Complete)
2	488729	Screw, 8-18 x 1/2
3	3395536	Clip

MISCELLANEOUS PARTS



Illus. No.	Part No.	DESCRIPTION
1	3359934	Miscellaneous Parts Bag
2	16123	Washer, Inlet Hose (4)
3	370445	Clamp, Hose
4	367594	Foot, Front (2)
5	358594	Foot, Rear (2)
6		Tie, Cable
7	3357331	Clamp, Hose (Upper Drain)

OPTIONAL PARTS (NOT INCLUDED)

For Models: LTE5243DQ5, LTE5243DT5 (Designer White) (Biscuit)

Illus. Part

No. No. DESCRIPTION

PAINT, TOUCH-UP (1/2oz.)

72017 White 4392899 Biscuit

PAINT, PRESSURIZED SPRAY

(12 oz.)

350938 Primer, Gray 350930 White 4392901 Biscuit

PAINT, BULK (1 qt.)

799344 White (Uncut) 4392900 Biscuit (Uncut)

ACCESSORY PARTS

685463 Kit, Grounding Plug, Dryer Side Panel 692790 White 3977784 Biscuit

OIL

350572 Oil, Gearcase (16 Oz.)

LUBRICANT

285208 Lubricant (Use Only in Brake Shoe Assembly On Roller and Pin)

SEALER

285195 Sealer, Gasket (.20 Fl. Oz.) (6 ml)